

RC -booster

RCB-CL

Owner's Manual

Specifications

Dimensions (w/d/h): 4.39" x 2.38" x 1.98" (110mm X 60mm X 50mm)
Weight: 0.6 lbs. (270g)
Power Consumption: 9vdc/5ma or 18vdc/6ma
Battery Type: 9vdc (006p) x 1
AC Adapter (optional): 9vdc -18vdc (Regulated Only)
Input Impedance: 1M Ω
Output Impedance: 10k Ω

Sample Settings



Blackface Blues Tone



Mid Boost

User Guide

DC JACK
when an external power supply is used, the battery is disconnected from the circuit. remove four screws from the bottom plate to access battery

GAIN

VOLUME

OUTPUT JACK

ON/OFF SWITCH



TREBLE

BASS

INPUT JACK

(nominal input -20dbu)
unplug when it's not in use for a longer battery life

Treble and Bass Control Range

